







### STEP2 Attaching brackets to Screen



32"-42" TV





42"-55" TV




### STEP1 Solid Concrete mounting




### STEP1 Wood stud mounting



### STEP3 Hang the TV onto the wall plate



# Setting static position



TENSION ADJUSTMENT  
AFTER WALL MOUNT INSTALLATION

## Warning

Do not adjust tension without putting on display





1. Ensure display has been put onto wall mount.
2. Read your display packaging or manual to find out display net weight.
3. Ensure display net weight between 5-23kg(11-50.6lbs).

+


clockwise to increase  
tension(carry more weight)

-

Anti-clockwise reduce  
tension(carry less weight)



$\pm 3^\circ$



$\pm 12^\circ$